

ds3484

User Manual Version 4.03




Table of Contents

| | |
|---|----|
| Documentation history..... | 3 |
| A quick look..... | 4 |
| Introduction..... | 5 |
| Getting started..... | 6 |
| Locating the IP Address..... | 7 |
| Configuring the dS3484..... | 9 |
| Status page..... | 10 |
| Network page..... | 11 |
| TCP/IP page..... | 12 |
| Webpage security..... | 14 |
| Configuring relays..... | 16 |
| Relay automation..... | 17 |
| Naming I/O's..... | 20 |
| Connecting I/O to Virtual Relays..... | 20 |
| Email notifications..... | 21 |
| Peer to Peer..... | 22 |
| Schedules..... | 23 |
| Counter/Timers..... | 25 |
| The application page..... | 28 |
| Application page security..... | 29 |
| Accessing your webpage from the internet..... | 30 |
| Boolean equations..... | 31 |
| TCP/IP command sets..... | 33 |
| ASCII command set..... | 33 |
| Binary command set..... | 36 |
| AES binary command set..... | 38 |
| Modbus commands..... | 40 |
| Function 01 (0x01) Read Coils..... | 40 |
| Function 04 (0x04) Read Input Registers..... | 40 |
| Function 05 (0x05) Write Single Coil..... | 40 |
| Function 15 (0x0F) Write Multiple Coils..... | 41 |
| Error code 1..... | 41 |
| Error code 2..... | 41 |
| Error code 3..... | 41 |
| Modbus Gateway..... | 41 |
| Loading the application firmware..... | 42 |
| Erasing old configuration settings..... | 44 |
| dS3484 hardware..... | 45 |
| LED indication..... | 46 |
| Power supply..... | 46 |
| Operating temperature..... | 46 |
| Power relays..... | 47 |
| Digital IO..... | 48 |
| Connection Examples..... | 49 |
| Analogue inputs..... | 50 |
| Serial Port Connections..... | 52 |
| dS3484 dimensions..... | 53 |
| Notes..... | 54 |

Documentation history

- V2.18 First release of separate dS3484 manual
- V2.19 Added new features:
Peer to Peer Use events to control relays on another dSxxxx module.
Schedules Create regular timed events
Counters Count input transitions or seconds
- v2.20 Minor update Documentation unchanged
- v3.01 Application update
Added ModBus function 15, Write Multiple Coils.
Increased to 32 relays. On dS3484, relays 5-32 are virtual relays.
Added CRC calculation to string arrays.
Added Modbus gateway to connect to downstream Modbus RTU modules.
Added settings for Modbus UID and downstream baud rate & parity.
Added independent Set, Reset and Toggle control boxes to relays.
Added ability to connect a virtual relay to a digital output.
Added power-up restore option for relays, restoring previous state.
Expanded application page to include virtual relays.
- IDE update
Updated to offer cross platform support
Now available under Windows, Linux & MAC OS X
- v4.01 Major update to the underlying dScript, now with functions and local variables.
Added "From Address" for easymail emails.
- v4.02 Bug fixes for the underlying dScript.
- v4.03 Editor update, added support for multiple editor tabs.
Compiler update, added support for multiple files in project.
Compiler update, added support for #ifdef, #else, #endif

A quick look

Ethernet connected module, 10/100Mb auto negotiated.

Relays – 4 x 16Amp 250Vac C/O.

I/O – 8 x digital I/O's NPN output, Volt free input.

4 x 10-bit analogue input

Power – 12VDC 1Amp supply required. 2.1mm center positive.

Connections – Screw Terminals for N/O N/C and Common contacts

PCB size – 156mm x 84mm

Controlled graphically by secure webpage or optionally one of ASCII, Binary or Modbus command sets over TCP/IP.

Email notifications – 8 selectable notifications, up to 100 emails/hour max.

Peer to Peer – Control relays on other modules.

Schedules – Able to schedule events based on time of day/week

Counter/Timers – Count or time events. 20 counts/second Max.

Also available when optionally programming in dScript are two TTL level serial ports and an RS485 serial port.

Introduction

The dS3484 is an Ethernet connected relay module featuring 4 channels of 16Amp 250Vac relays. Each relay has both normally open (NO) and normally closed (NC) as well as the common available on three terminals.

In addition to the relays, the dS3484 has 8 digital I/O channels and 4 x 10-bit analogue input channels (0v-3.3v input range).

The dS3484 requires a 12v 1Amp power supply such as this one:

<http://www.robot-electronics.co.uk/universal-12vdc.html>

The dS3484 has four built in control methods.

Primary control method is graphically by using its built in secure website.

Secondary control may be one of:

ASCII - type in commands via a program such as PuTTY.

Binary - Command set using binary codes

Modbus – Functions 1, 4, 5 and 15 supported

And if you should wish to modify the supplied firmware – you can.

Behind the scenes there is dScript, a powerful multi-threaded operating system and programming language. The supplied firmware is written in dScript as well as HTML, CSS and Javascript on the webpages and the full source is in the separately downloadable dScript support package.

You do not need to use dScript at all, but its great to know its there - just in case you do.

Getting started

Start by plugging in the Ethernet cable to connect the module to your network, and the 12v jack plug from your adapter. Switch on and the first thing you will note is that the blue LED will flash 3 times. This indicates that the control firmware is loaded on the module. *(If the blue led does not flash you will need to load in the control firmware. Don't worry, this is very easy to do. Just go to the chapter on installing the firmware and follow the instructions there).*

If you are using a Win7/8/10 PC, open your browser and into the address bar (not the search bar) type:

<http://dS3484/index.htm>

You should now see the application webpage and you can control relays and I/O's.

dScript


| | | | |
|----------|----------|----------|----------|
| Relay 1 | Relay 2 | Relay 3 | Relay 4 |
| Relay 5 | Relay 6 | Relay 7 | Relay 8 |
| Relay 9 | Relay 10 | Relay 11 | Relay 12 |
| Relay 13 | Relay 14 | Relay 15 | Relay 16 |
| Relay 17 | Relay 18 | Relay 19 | Relay 20 |
| Relay 21 | Relay 22 | Relay 23 | Relay 24 |
| Relay 25 | Relay 26 | Relay 27 | Relay 28 |
| Relay 29 | Relay 30 | Relay 31 | Relay 32 |




| | | | | |
|-----|--------------------------------|------|----------------------------------|--------------------------------|
| AD1 | <input type="text" value="0"/> | Ctr1 | <input type="text" value="253"/> | <input type="text" value="0"/> |
| AD2 | <input type="text" value="0"/> | Ctr2 | <input type="text" value="0"/> | <input type="text" value="0"/> |
| AD3 | <input type="text" value="0"/> | Ctr3 | <input type="text" value="0"/> | <input type="text" value="0"/> |
| AD4 | <input type="text" value="0"/> | Ctr4 | <input type="text" value="0"/> | <input type="text" value="0"/> |

Locating the IP Address

If you are not using a windows PC then you will need to find the IP address of the module. The simplest method is connect the module (Ethernet, USB then lastly, Power) and load up the dScript editor.




Go to Module→Select Port and make sure the correct serial port is selected as illustrated above.



Now go to Module→ IP Address and the current IP address is displayed.


Make sure the Ethernet is connected before you apply power. If you plug the Ethernet cable in after the power, the module will already have booted with a default IP address.

Alternatively, you can find the IP address of the module by checking your DHCP server. If you have a DHCP server on your network (your router is normally the DHCP server) then the dS3484 will get its IP address from that. Log on to your router and navigate to the LAN client list.



Above is the entry from our ASUS RT-N66U router. So now you type: 192.168.0.64/index.htm into your browser address bar and you should see the application webpage shown on the previous page.

If you prefer, you can download a java program that will run on Windows, MAC or Linux, and will list all of our modules that are connected to your LAN. [DevantechModuleFinder.jar](#)



If you do not have a DHCP server the dS3484 will use a default IP address of 192.168.0.123 so make sure your PC is on the same subnet of 255.255.255.0 and its IP address is 192.168.0.xxx

Configuring the dS3484

There are a set of configuration pages to get the dS3484 operating as you want it. These pages are all `_configx.htm`, (that's a leading underscore character).
ie.

`_config.htm`
`_config2.htm`

Anything that starts with `_config` is considered a special name for configuration pages and can only be seen if you have the the USB cable plugged in and connected to your PC.

Why only if the USB cable is plugged in?

Its an additional security measure. After you have configured and deployed the module, you really don't want these configuration pages available for others to change. So with the USB cable disconnected the `_config` pages are not available. If you try to access them you just get served a "not authorised" page instead.

So for now, you do want to look over the config pages. If you have a Win10, Linux or MAC PC, you can go right ahead and plug in the USB cable. These machines will install their own USB drivers. We won't be sending anything to the board, its just the presence of the USB connection that enables the config pages to be served. If you have a Win7 or Win8 PC you will need to install the drivers. (*go to the chapter on installing the firmware and follow the instructions there*).

With the USB cable connected, browse to:
`192.168.0.64/_config.htm`
(substituting your IP address)

Status page

You should now see the following page:

| Module | dS3484 |
|----------------------|----------|
| System Firmware | 4.1 |
| Supplied Voltage | 12.0 Vdc |
| Internal Temperature | 30.8 °C |

This status page shows you the system and application firmware revisions as well as the supplied voltage to the board and its internal temperature.

If you hover your mouse cursor over the menu buttons on the left, the help panel will give you an overview of each one.


Network page

dS3484 System Configuration Devantech Ltd

Status
Network
TCP/IP
Webpage Security
Relays
Input/Output
Email
Peer to Peer
Scheduler
Counter/Timer
Application Page

Host Name
IP Address
Subnet Mask
Gateway Address
Primary DNS
Secondary DNS
Enable DHCP

Network
Configure network IP address and associated parameters.

 Update Pending

Notice that everything below the Host Name is greyed out and can't be changed. This is because the "Enable DHCP" box is checked and all the greyed out fields are supplied by the DHCP server. Although a quick way to get you connected, we really do not recommend this as the DHCP server can assign a different IP each time you power up. If you want to control this module from the internet while you are away from the premises then you will be setting up port forwarding on your router which requires a fixed IP address.

So lets do that first.

Uncheck the DHCP box and you can then set all the other fields. Notice that the Red "Update Pending" light comes on. It indicates there are changes which have not yet been written to the flash memory. It will go off again 5 seconds after you stop changing anything.

Choose an IP address for the module, something outside of the DHCP settings on your router so it will not assign anything to that address.

The subnet mask, Gateway and DNS can all be left as the defaults.

Network changes only take effect after the next re-boot, so wait until the "Update Pending" light goes out and give the reset button on the module a quick press. The Green Led will light and the Blue led will flash 3 times. You will now find the module at your new IP address. If the Red led comes on after you press the reset button, its because you pressed it for too long (and entered bootloader mode). Just have another go with the reset button for a bit less time.

Your browser won't know you have changed the IP address so it will still be showing the old, now dead page. Make sure you change to your new IP address and load the page again.

TCP/IP page

The TCP/IP tab allows you to select one of three command sets to control the module. These are independent of, and separate to the HTML webpage control.

The screenshot shows the 'dS3484 System Configuration' interface. On the left is a vertical menu with buttons for: Status, Network, TCP/IP (highlighted), Webpage Security, Relays, Input/Output, Email, Peer to Peer, Scheduler, Counter/Timer, and Application Page. The main area contains configuration options: ASCII (checked), ModBus (unchecked), Binary (unchecked), AES Binary (unchecked), TCP/IP Port (input field with '17123'), and AES key (input field with 'This MUST be 32 ch'). On the right, a 'TCP/IP' section contains the text: 'Choose the TCP/IP command set to use, or disable all check boxes for none.' At the bottom right, there is a 'Update Pending' indicator with a circular arrow icon.

Clicking on one of the four check boxes will select that command set. Only one command set may be selected. You can disable all TCP/IP command sets by clicking on an already selected box.

The ASCII command set is text based. You can use any program that can send text over TCP/IP. We use PuTTY in raw mode. The Binary command set operates in a similar way to our ETHxxx range of boards (but uses different commands), by sending binary commands to the module. AES Binary adds encryption. Note the AES key MUST be 32 bytes long. We have test applications written in C# and Java to demonstrate AES encryption.

When selecting the Modbus commands, an additional set of configuration boxes are available.

The screenshot shows the 'dS3484 System Configuration' web interface. On the left is a vertical menu with buttons for: Status, Network, TCP/IP (highlighted), Webpage Security, Relays, Input/Output, Email, Peer to Peer, Scheduler, Counter/Timer, and Application Page. The main area contains configuration options for Modbus: ASCII (checkbox), ModBus (checkbox checked), Binary (checkbox), AES Binary (checkbox), TCP/IP Port (text input with '502'), AES key (text input with 'This MUST be 32 ch'), Modbus UID (text input with '1'), Modbus Baudrate (dropdown menu with '9600'), and Modbus Parity (dropdown menu with 'Even'). On the right, a 'TCP/IP' section contains the text: 'Choose the TCP/IP command set to use, or disable all check boxes for none.' At the bottom right, there is a circular refresh icon and the text 'Update Pending'.

These allow you to select the UID, normally you will leave this at the default of 1. The dS3484 will respond to commands on this UID. If you send any other UID it will be treated as the address of a Modbus module connected to the RS485 port. Commands to other UID's will be converted to Modbus RTU format and sent out on the RS485 port. Any responses will be converted back to Modbus/TCP format and returned to you.

The second box selects the baud rate of the Modbus RTU line and the third box selects even, odd or no parity.

The Modbus command set implements functions 1, 4, 5 and 15.

When selecting the Modbus command set, make sure you select port 502 which is the official port number for Modbus over TCP/IP.

A full description of the commands is in the "Command Sets" section later in this manual.

Webpage security

Allows you to prevent unauthorised personnel from accessing the application webpage or using it to control the module.

The screenshot shows the 'Webpage Security' configuration page in the dS3484 System Configuration interface. On the left is a navigation menu with buttons for Status, Network, TCP/IP, Webpage Security (highlighted), Relays, Input/Output, Email, Peer to Peer, Scheduler, Counter/Timer, and Application Page. The main content area has the following settings:

- Enable `_pw.htm`
- Security Password
- HTTP Port

On the right, a box titled 'Webpage Security' contains the text: 'Configure the password for webpage security.' At the bottom right, there is a circular indicator with a grey dot and the text 'Update Pending'.

Leaving the Security Password blank will disable it and allow everyone to access the application page to control the module.


To enable password protection enter a password into the Password box. You can use any characters from the ASCII character set from 0x20 to 0x7E except " (0x22). It may be up to 200 characters long and you don't have to memorise it, so make it a long one with plenty of uppercase, lowercase, numbers and symbols.

Accessing a special webpage, `_pw.htm`, will install the password on your browser. To do this make sure the Enable `_pw.htm` box is checked.

This close-up shows the 'Enable `_pw.htm`' checkbox checked, the 'Security Password' field containing the text 'myNewPassword', and the 'HTTP Port' field containing '80'.

When the "Update Pending" light goes out, re-boot the module and go to `yourIP/_pw.htm`

You will see something like this:



The password is now loaded on your browser. Do the same for any further browsers you want to enable. When you have done uncheck the "Enable _pw.htm" box to prevent anyone else from loading the password. When the "Update Pending" light goes out re-boot the module again.

The default port used by html webpages is 80. You can change this if required. If you do so then you will need to include the port number in the address. If you change the port to 2345 then the webpage will be at:
YourIP:2345/index.htm
For example:
192.168.0.123:2345/index.htm


Configuring relays

The next tab allows you to set the names of the 32 relays that will be displayed on the application page.



Use the Relay No. box to select the relay to configure. There are 32 relays available. Relays 1-4 are the physical relays on the module. Relays 5-32 are virtual relays, they have no physical presence but otherwise behave the same as the real ones. I/O lines may be linked to virtual relays to provide additional physical outputs, see next section for details.

Names may be up to 20 characters long, but keep them shorter if you want to use a phone as the controller. Here we have renamed relay 1 as "YardLights" and those 10 characters are a comfortable size on a vertical phone screen.



Relay automation

There are a set of control boxes that provide for autonomous relay operation. If you just want to control the relays from the webpage or using one of the TCP/IP modes, then leave these boxes blank.

Relay No. box

This selects the relay you wish to configure. There are 32 relays available. The first 4 relays are the actual relays on the module. Relays 5-32 are virtual relays. They have no physical presence but otherwise behave identically to the real ones. They can provide additional processing and a larger control surface to your application.

Pulse/Follow box

If you place a number in this box then that is the pulse time for the relay in mS (1000mS = 1 second). The minimum value is 100mS. The maximum is 2147483647 (more than 24 days). When the relay is toggled on, timing begins and at the end of the time period the relay goes off again. If the button is pressed again during timing then the timing is restarted.



The screenshot shows a dark-themed control panel with the following elements:

- Relay No.:** A dropdown menu currently showing '1'.
- Relay Name:** A text input field containing 'YardLights'.
- Pulse/Follow:** A text input field containing '1800000'.
- Set Relay:** A button.
- Reset Relay:** A button.
- Toggle Relay:** A button.
- Power-up Restore:** A checkbox that is currently unchecked.

The above example will turn off the yard lights after 30 minutes. 1800000 mS is 1800 seconds. 1800 seconds is 30 minutes.

It also possible to insert a boolean equation into the box. Boolean equations are just simple equations that evaluate to a 0 or 1. For example Relay 1 is referred to as R1. Input1 is referred to as D1 (Digital 1). Analogue input 1 is referred to as A1.

Here's a very simple example:



Relay No. 1 ▾
Relay Name YardLights
Pulse/Follow R2
Set Relay
Reset Relay
Toggle Relay
Power-up Restore

Enter R2 into the Relay 1 Pulse/Follow box. This will make relay 1 copy whatever you do to Relay 2. Try it!

Now change it to !R1.



Relay No. 1 ▾
Relay Name YardLights
Pulse/Follow !R2
Set Relay
Reset Relay
Toggle Relay
Power-up Restore

The exclamation mark is read as "Not R1". Now relay 1 will always be the opposite of relay 2. Try it.

Boolean equations may be used for controlling relays and other objects such as email. See the "Boolean equation" section later in this manual for full documentation.

Set Reset & Toggle boxes

When used, these three controls contain boolean equations. The "Set Relay" box will set the relay when the boolean equation becomes true. The other two boxes reset and toggle the relay when the boolean equation become true.

This is important! The Set, Reset and Toggle controls are transitory (edge triggered) controls.

The relays are only affected at the moment the boolean equation becomes true. This differs from the Follow box where the relay continuously follows the output state of the equation.

In the previous example where we placed R2 in relay 1's Follow control, relay one will always be the same as relay 2. If relay 2 is off and we click relay 1 (YardLights) nothing will happen.

However if we want relay1 to be controlled by relay 2 as above, and also want to be able to toggle it on/off from the webpage, we can put R2 in the "Set Relay" box and !R2 in the "Reset Relay" box.

| | |
|------------------|--------------------------|
| Relay No. | 1 ▼ |
| Relay Name | YardLights |
| Pulse/Follow | |
| Set Relay | R2 |
| Reset Relay | !R2 |
| Toggle Relay | |
| Power-up Restore | <input type="checkbox"/> |

Try it.

Power-up restore

When checked, the relay is restored to the previous state it had when power was lost. If the relay was on when power was lost or the module was turned off, then the relay will be turned on when the module is powered up again.

Naming I/O's

The I/O Names tab is used to assign meaningful names to the I/O terminals.

The screenshot shows the 'dS3484 System Configuration' web interface. On the left is a navigation menu with buttons for Status, Network, TCP/IP, Webpage Security, Relays, Input/Output (selected), Email, Peer to Peer, Scheduler, Counter/Timer, and Application Page. The main area displays configuration for I/O terminals. I/O 1 through I/O 8 each have a text input field containing 'I01' through 'I08' and a dropdown menu set to 'None'. Below these are four 'AD' (Analog Digital) terminals, AD1 through AD4, each with a text input field containing 'AD1' through 'AD4'. On the right, a box titled 'I/O Names' contains the text: 'These are the I/O labels on the application page to give each I/O a unique and descriptive name. Maximum 20 characters.' At the bottom right, there is a 'Update Pending' indicator.

As with relay names these may be up to 20 characters long, but do check it looks ok on a mobile device or whatever you are using to control the module.

Connecting I/O to Virtual Relays

A close-up of the I/O configuration interface. It shows four rows for I/O 1, I/O 2, I/O 3, and I/O 4. Each row has a text input field with the label 'I01' through 'I04' and a dropdown menu. The dropdown for I/O 1 is open, showing the number '5' selected. The other dropdowns are closed and show 'None'.

Any of the eight digital I/O lines may be connected to a virtual relay. This gives the digital output the same automation capabilities as the relays. Enter the relay number in the link box as shown above. Any relay may be selected for an I/O.

Email notifications

The final configuration tab is the Email tab for sending secure, AES encrypted email notifications from the module.

The screenshot displays the 'dS3484 System Configuration' web interface. On the left, a vertical sidebar contains buttons for various configuration sections: Status, Network, TCP/IP, Webpage Security, Relays, Input/Output, Email (highlighted), Peer to Peer, Scheduler, Counter/Timer, and Application Page. The main configuration area is titled 'Email No. 1' and includes three input fields: 'Email Address' with the value 'yourname@example.com', 'Subject' with 'Event message goes here', and 'Trigger' with 'For example, D1'. To the right, a box labeled 'Easy Mail' contains the text 'Send secure emails in response to selected events.' At the bottom right of the interface, there is a circular 'Update Pending' indicator.

Up to eight (8) email notifications may be set up, selected with the Email No. box.

Setting up emails is quick and easy. You just need the recipients email address, a notification message which will be the email subject line and the trigger event.

The trigger event uses the same boolean equation solver as the relay automation. So if you want to trigger an email when digital input 1 (I/O1) becomes active, just enter D1.

The email message is automatically filled in with useful information on the state of the relays, I/O's etc.

Boolean equations are used for controlling relays as well as triggering email notifications.

See the "Boolean equation" section later in this manual for full documentation.

Note - Email notifications are limited to 100/hour.

Peer to Peer

This tab allows you to configure events on this module to control relays on another.

The screenshot shows the 'Peer to Peer' configuration page in the dS3484 System Configuration web interface. On the left is a vertical menu with buttons for Status, Network, TCP/IP, Webpage Security, Relays, Input/Output, Email, Peer to Peer (selected), Scheduler, Counter/Timer, and Application Page. The main area contains configuration fields: P2P No. (dropdown menu with '1' selected), Input (text box with 'D1'), Target IP (text box with '192.168.0.130'), Target Port (text box with '17123'), Target Relay No. (text box with '1'), Target Action. (text box with '1'), TCP/IP Timeout. (text box with '5000'), and Use AES (checkbox checked). On the right, a text box titled 'Peer to Peer' explains: 'Use inputs on this module to control relays on other dSxxxx modules which can be on your local LAN or across the internet.' At the bottom right, there is a 'Update Pending' indicator.

Up to eight (8) Peer to Peer events may be set up, selected with the P2P No. box.

Control of the target relay is by using the binary command set only. This can optionally use AES encryption. The Target module must be set to either Binary or AES Binary mode on its TCP/IP tab, and this "Use AES" checkbox set to match.

The input box selects the event that will be used to control the target relay. This can be as simple as an input, or a complex Boolean equation. See the "Boolean equation" section later in this manual for full documentation.

Target IP, Port & Relay No should be set to locate the target relay.

Target action determines how the relay will be controlled.

0 – No action, this Peer to Peer event is disabled.

1 – Follow Me, the relay will follow the input, (or the Boolean result of any equation here).

2 – Set Relay, the relay will be set by this event. You will need another P2P event to reset it.

3 – Reset Relay, the relay will be reset by this event. You will need another P2P event to set it.

4 – Toggle Relay, this will toggle the relay each time the event is triggered.

100+ – Pulse relay, Pulse times are in mS. (1000mS=1Second).

5-99 will have no action.

Schedules

The scheduler can schedule regular events. These can be once or twice daily with the two start and stop times and can happen on any selected weekdays.

The screenshot shows the 'Scheduler' configuration page in the dS3484 System Configuration interface. The page includes a sidebar with navigation buttons and a main configuration area. The configuration area contains the following fields and options:

- Schedule No. (dropdown menu set to 1)
- Target Relay (input field set to 3)
- W/Days (checkboxes for S, M, T, W, T, F, S, with W, T, F highlighted in red)
- Start 1 (Hours: 6, Minutes: 30, Seconds: 0)
- Stop 1 (Hours: 7, Minutes: 15, Seconds: 0)
- Start 2 (Hours: 16, Minutes: 30, Seconds: 0)
- Stop 2 (Hours: 22, Minutes: 45, Seconds: 0)
- Current Time (Hours: 15, Minutes: 56, Seconds: 17)
- Time Zone (input field set to 0)
- Daylight Saving (checkbox checked)

A 'Scheduler' text box on the right contains the text: 'Scheduler Schedule daily events with 8 schedules, 2 events per schedule and a week day mask.' At the bottom right, there is a 'Update Pending' indicator.

The Schedule No. is one of eight schedules that can be set up, selected with the Schedule No. box.

The target relay is the local relay that you want this schedule to control.

W/Days selects the days of the week you want this schedule to control the relay. When highlighted in red, the weekday is active.

There are two sets of Start and Stop times for each of the eight schedules. The relay is set when the start time transitions from inactive to active, ie. at the start time, and reset when the stop time is reached. It is not held on or off. It can be changed by other events including the webpage buttons.

The current time originates from an internet time server. It is read only and cannot be changed. Therefore you must have an internet connection for the scheduler to operate correctly.

The timezone allows you to set the time for your location.

For example;
GMT leave this at 0.
CET set this to 1.
PST set this to -8
IST set this to 5:30

Daylight saving time may be checked if required. It advances the time by 1 hour between the last Sunday in March and the last Sunday in October.

As well as controlling a relay directly, schedules may also be used in the boolean equation fields of other controls. A relay could be controlled by placing S1 (for schedule 1) in its automation field.

Counter/Timers

Count input pulses or time events.

The screenshot shows the 'dS3484 System Configuration' web interface. On the left is a navigation menu with buttons for Status, Network, TCP/IP, Webpage Security, Relays, Input/Output, Email, Peer to Peer, Scheduler, Counter/Timer (highlighted), and Application Page. The main content area displays configuration for Counter No. 1. The settings are: Counter No. 1 (dropdown), Counter No. 1 (input), Counter Name Ctr1 (input), Count Input T1 (input), Capture Input D7 (input), Reset Input D8 (input), Current Value 44 (input), and Captured Value 0 (input). On the right, there is an 'Easy Mail' section with the text 'Send secure emails in response to selected events.' At the bottom right, there is a 'Update Pending' button.

There are a total of eight counter/timers available, selected with the Counter No. box. . Each counter can count at a maximum speed of 20Hz (20 counts per second).

Counter Name

Each counter/timer may be named and this name appears on the application page and email notifications.

Count Input

Each counter/timer is capable of being a timer by entering T1 into its count input box. T1 is an internal 1Hz timer that will advance the count once per second. If an input is specified then any pulses on that input will be counted. D4 will count pulses on input 4.

Capture Input

This is the event that will cause the current counter value to be stored in the capture register. The capture register is displayed on the application page, and may also be read using the TCP/IP commands.

Reset Input

This input will reset the counter value to zero. If the capture Input has been left blank then it will store the current counter value in the capture register before resetting it to zero. You may use an input such as D3 or you can use the counter value itself. Entering C1>9 for the counter1 Reset Input will reset the counter when it reaches 10. This will create a repeating 10 step timer (0-9).

Counters, Timers and Schedules can be combined. As an example lets assume we want to count the pulses on input 2. We need to know the number of pules per hour coming in. First we need a 1 hour time base, we'll use counter/timer 1 for this.

| | |
|----------------|---------|
| Counter No. | 1 ▼ |
| Counter Name | Ctr1 |
| Count Input | T1 |
| Capture Input | |
| Reset Input | C1>3599 |
| Current Value | 17 |
| Captured Value | 0 |

Using T1 for the count input will make the counter increment once per second. There are 3600 seconds in 1 hour so we reset the counter when its greater than 3599 with C1>3599. The counter will count from 0-3599.

Next we will use counter 2 to do the counting of input 2 pulses.

| | |
|----------------|------|
| Counter No. | 2 ▼ |
| Counter Name | Ctr2 |
| Count Input | D2 |
| Capture Input | |
| Reset Input | C1<1 |
| Current Value | 0 |
| Captured Value | 0 |

The count input is set to D2 to count the pulses. The reset input is controlled be counter 1. When it gets reset to zero each hour, so does counter 2. As the capture input is blank the reset event also captures the count value. This may be read any time in the next hour.

The internal time base, T1 is derived from the crystal on the module. It's accurate but will drift over time so that the capture event may not happen "on the hour". Even if you started it on the hour it will drift out by a few seconds a day. So as a final refinement we will synchronize our time base with the real time derived from a schedule.

| | | | | | | | |
|-----------------|--------------------------|---------|---------|---|---|---|---|
| Schedule No. | 1 ▼ | | | | | | |
| Target Relay | 0 | | | | | | |
| W/Days | S | M | T | W | T | F | S |
| | Hours | Minutes | Seconds | | | | |
| Start 1 | 0 | 0 | 0 | | | | |
| Stop 1 | 0 | 0 | 2 | | | | |
| Start 2 | 0 | 0 | 0 | | | | |
| Stop 2 | 0 | 0 | 0 | | | | |
| Current Time | 13 | 3 | 1 | | | | |
| Time Zone | 0 | | | | | | |
| Daylight Saving | <input type="checkbox"/> | | | | | | |

The target relay is set to zero as we don't need to use any relays for this. All week days are set so we perform the synchronization every day. Start/stop time 1 is used to activate the schedule at 1 second past midnight each day. The second start/stop time is disabled as both times are identical.

| | |
|----------------|------------|
| Counter No. | 1 ▼ |
| Counter Name | Ctr1 |
| Count Input | T1 |
| Capture Input | |
| Reset Input | C1>3599 S1 |
| Current Value | 26 |
| Captured Value | 0 |

Go back to counter1 and add "|S1" to the reset input. Now our time base timer will reset every hour or when schedule1 triggers it.

The application page

The last tab in the configuration pages takes you directly to the application page so you can quickly see the results of your configuration changes.

dScript

| | | | |
|----------|----------|----------|----------|
| Relay 1 | Relay 2 | Relay 3 | Relay 4 |
| Relay 5 | Relay 6 | Relay 7 | Relay 8 |
| Relay 9 | Relay 10 | Relay 11 | Relay 12 |
| Relay 13 | Relay 14 | Relay 15 | Relay 16 |
| Relay 17 | Relay 18 | Relay 19 | Relay 20 |
| Relay 21 | Relay 22 | Relay 23 | Relay 24 |
| Relay 25 | Relay 26 | Relay 27 | Relay 28 |
| Relay 29 | Relay 30 | Relay 31 | Relay 32 |



| | | | | |
|-----|--------------------------------|------|----------------------------------|--------------------------------|
| AD1 | <input type="text" value="0"/> | Ctr1 | <input type="text" value="253"/> | <input type="text" value="0"/> |
| AD2 | <input type="text" value="0"/> | Ctr2 | <input type="text" value="0"/> | <input type="text" value="0"/> |
| AD3 | <input type="text" value="0"/> | Ctr3 | <input type="text" value="0"/> | <input type="text" value="0"/> |
| AD4 | <input type="text" value="0"/> | Ctr4 | <input type="text" value="0"/> | <input type="text" value="0"/> |

The I/O indicators show grey when the I/O is inactive. Red indicates an active input/output.

The I/O's are clickable just like the relay buttons to turn them on and off.

Application page security

The configuration pages (any page name starting with `_config`) are only served when the USB port is connected. If the USB port is unplugged then no configuration pages are served. Instead, you will be served a page saying "You do not have permission to view this page."

The `_pw.htm` page (which contains the javascript that loads the password into your browser) will only be served when the enable `_pw.htm` checkbox is checked on the Webpage Security tab.

If the password field is left blank, the application page will always be served – to anyone! Entering a password means the application page will only be served to a browser that has the matching password set. Everyone else will just be served a simple webpage saying "You do not have permission to view this page."

To summarize, set a password, load it onto your browser, disable `_pw.htm` and un-plug the USB cable. Now you, and only you, can access and control your module.

Accessing your webpage from the internet

Now you have your webpage up and running on your local network, for example 192.168.0.150, and you can access the webpage and control the module. You just go to 192.168.0.150/index.htm, and the page is there.

However you can't get directly at that page from your phone when you are away from home. You can't access it on 192.168.0.150 because your network is not publicly accessible, its a private network address. You will have another IP address. This is the one your ISP gave you for your internet connection, and is the public IP address of your router on the internet. If you don't know what it is you can type "my ip" into Google's search bar and it will tell you. This is the IP address you will use to access the modules webpage.

Everything on the internet uses an IP address and a port number.

When you access a webpage in your browser all you enter is the IP address (or more likely a domain name, but its ultimately translated to an IP address). You don't normally have to enter a port number but its still required. Your browser simply uses the default port number, which is 80 for the web, unless otherwise specified our modules also use port 80 for the webpage. However its a good idea to use a different port number for our boards as this will avoid conflict with any web server you may have on your network.

Pick a number, I'll choose 19321 as our port number. Just make sure its different from any TCP/IP port number you are using. The HTML port is set on the Webpage Security tab.

After you have re-loaded the program you can access the webpage with:
192.168.0.150:19321/index.htm

Note that as we have changed the modules html port we need to tell the browser how to find the page with the new port number. Do that by inserting a ':' character and the port number between the IP address and the page name as shown above.

Assuming your routers internet IP address is 86.87.88.89 (I made that up – replace with your actual IP address) you will access the page from anywhere with address:
86.87.88.89:19321/index.htm

However first you have to set up your router to do that.

It's called "port forwarding" or "virtual server", but whatever your router calls it, you need to set it up so that all incoming connections on port 19321 are forwarded to port 19321 on local IP address 192.168.0.150.

Unfortunately there are so many routers out there we cannot give details on all of them. You should consult your routers manual or search Google for details on your specific router.

Boolean equations

Boolean equations are used in a number of places in the configuration screens. They are used for relay automation, triggering emails and peer to peer events and the count, capture and reset for the counter/timers.

The types that can be used in boolean equations are:

1. Relays, R1 – R2
2. Digital I/O's, D1 – D4
3. Analog inputs, A1 – A2
4. Schedules, S1 – S8
5. Counters, C1 – C8
6. 1Hz Time base, T1

The simplest equation is R1. This is true when R1 is active and not true when R1 is in-active. If you enter R1 in the relay 2 automation box it will simply follow whatever R1 does.

The exclamation mark ! is used as a "not". So !R1 is true when relay 1 is in-active. Enter !R1 in the relay 2 automation box it will follow the opposite of R1. Relay 2 will be active when relay 1 is inactive.

The same applies to the digital I/O's. Enter D2 in the relay 2 automation box and the relay will follow the input.

Analog inputs and Counter values are compared with a number to obtain a true/false boolean result. In this example we will use analogue input 1. Then we can enter $A1 < 1000$ in the relay2 automation box. This will turn on relay 2 when the input A1 falls below 1000. If A1 is connected to a temperature sensor and R2 controls a heater – well, you get the idea. Analog comparisons use the "less than" < and "greater than" > symbols only. There is no equal or not equal. Checking for equality on a potentially jittery analogue input is not really useful.

As well as "not" !, you can use "and" & and "or" | in your equations.
Enter $D2 \& D3$ and the result is true only when both D2 and D3 are active.
Enter $D2 | D3$ and the result is true when either D2 or D3 is active.

What happens here:

$D2 | D3 \& D4$

The answer is that boolean expressions are evaluated left to right. So D2 is ORed with D3 and the result ANDed with D4. You can change the order of precedence by using parenthesis ().

$D2 | (D3 \& D4)$

will now AND D3 with D4 and the result is Ored with D2.

To demonstrate a real world example, take the analog example above where we compared A1 with 1000 to operate R2. Whilst this would work its a not a good solution as the relay would jitter badly when A1 was hovering between 999 and 1000. What we need is some hysteresis. To do that we will use R2 in its own equation.

$(A1 < 1000 \& !R2) | (A1 < 1234 \& R2)$

Assume R2 is inactive (off). The 2nd half of the equation $(A1 < 1234 \& R2)$ will have no effect.

So when A1 falls below 1000 the relay comes on. Now the 2nd half of the equation is true, and will stay true until A1 climbs above 1234.

So the relay becomes active when A1 is below 1000 and inactive above 1234.


We have hysteresis!

TCP/IP command sets

There are four TCP/IP command sets on four selectable check boxes, of which one or none may be selected on the TCP/IP config tab. These are ASCII, Modbus, Binary and Binary with AES256 encryption.


ASCII command set

The ASCII command set allows you to type commands using a TCP/IP terminal program such as PuTTY. Use PuTTY in raw mode.




The screenshot shows the 'Basic options for your PuTTY session' dialog box. It contains a section 'Specify the destination you want to connect to' with two input fields: 'Host Name (or IP address)' containing '192.168.0.25' and 'Port' containing '17123'. Below this is the 'Connection type:' section with five radio buttons: 'Raw' (selected), 'Telnet', 'Rlogin', 'SSH', and 'Serial'.

Make sure you have you module set to ASCII mode and, after the “update Pending” indicator has gone out, re-booted the module so the changes take effect.



The screenshot shows a configuration menu with the following items: 'ASCII' with a checked checkbox, 'ModBus' with an unchecked checkbox, 'Binary' with an unchecked checkbox, 'AES Binary' with an unchecked checkbox, 'TCP/IP Port' with a text input field containing '17123', and 'AES key' with a text input field containing 'This MUST be 32'.

ASCII commands are all two character commands and are not case sensitive. Type ST followed by the return key. This is the SStatus command. You will see:



```
192.168.0.25 - PuTTY
ST
Module Type: dS3484
Firmware Version: 2.19
Application Firmware Version: 1.3
Supply Voltage: 12.0
Board Temperature: 24.1C
█
```

Valid commands are:

ST SStatus request

SR [Relay number] [on/off] {Pulse time in mS}

SR 1 on Set Relay 1 on

SR 1 off Set Relay 1 off

SR 1 on 1000 Set Relay 1 on for 1 second

SO [Output number] [on/off]

SO 1 on Set Output 1 on

SO 1 off Set Output 1 off

GR [Relay number]

GR 1 Get relay 1 status – responds with Active or Inactive

GI [Input number]

GI 1 Get Input 1 status – responds with Active or Inactive


GA [Analog Input number]

GA 1 Get Analog input 1 – responds with the 10-bit analog value

GC [Counter number]

GC 1 Get Counter 1 – responds with count and capture values.

Typical PuTTY session.



```
192.168.0.25 - PuTTY
ST
Module Type: dS3484
Firmware Version: 2.19
Application Firmware Version: 1.3
Supply Voltage: 12.1
Board Temperature: 24.4C
SR 1 on
Ok
SR 2 on 1000
Ok
SO 1 on
Ok
GR 1
Active
GI 1
Active
GA 1
759
GC 1
3310, 1651
█
```

Binary command set

Summary.

0x30 Get Status
0x31 Set relay
0x32 Set output
0x33 Get Relays
0x34 Get Inputs
0x35 Get Analogue
0x36 Get Counters

0x30 (decimal 48) Get Status (1 byte command, returning 8 bytes)

This command returns 8 bytes of status data

| | |
|----------------------------------|---|
| Module ID | This will be 30 (0x1E) for the dS3484 |
| System Firmware Major | 2 for example |
| System Firmware Minor | 18 for example |
| Application Firmware Major | 1 for example |
| Application Firmware Minor | 2 for example |
| Volts | Power supply volts x 10. Example 125 is 12.5v |
| Internal Temperature (high byte) | x 10 |
| Internal Temperature (low byte) | combined to 16 bits, 267 = 26.7 degrees C |

In the above example the returned bytes would be:

0x1E 0x02 0x12 0x01 0x02 0x7D 0x01 0x0B

The last two bytes combined are 0x10B which is 267 decimal.

0x31 0x02 0x01 0x00 0x00 0x00 0x00 Set Relay (7 byte command, returning 1 byte)

This command turns a relay on or off or pulses it for a time period and returns an ACK/NACK byte. ACK=0, NACK=non-zero (actually the unknown relay number).

0x31 The actual command, the rest are parameters.
0x02 Relay number. Valid numbers are 1-8 (0x01-0x08)
0x01 Turn relay on (0x00 for off). This is ignored when following pulse time is >100.
0x00 } high byte Pulse time
0x00 } mid high These 4 bytes combined are a 32-bit pulse time for the relay
0x00 } mid low when less than 100 (as it is here 0x00000000) its ignored
0x00 } low byte When >100 this pulses relay on for that number of mS

To pulse relay 5 on for one second the command is:

0x31 0x05 0x00 0x00 0x00 0x03 0xE8

0x000003E8 (or just 0x3E8) is 1000 decimal, which is 1000mS or 1 second.

The relay will turn on and then go off 1 second later.

When sending a relay pulse time, the relay on/off byte is ignored. The relay is always on for the duration of the pulse.

Binary Command Set – continued.

0x32 0x04 0x01 Set Output (3 byte command, returning 1 byte)

This command turns an output on or off and returns an ACK/NACK byte. ACK=0, NACK=non-zero (actually the unknown I/O port number).

All I/O's which need to be inputs should have the output turned off. When turned on the NPN transistor can sink up to 100mA.

0x32 The command, the rest are parameters

0x04 the I/O number, 4 in this case.

0x01 on (0x01) or off (0x00)

0x33 0x01 Get Relay (2 byte command – returning 5 bytes)

This command is used to get the states of the relays. The second byte is the relay number, relay 1 in this case.

The first returned byte is the state of the requested relay, 0x00 (off) or 0x01 (on).

The next four bytes pack the states of all 32 relays (virtual and actual relays). Bit 7 of byte 2 is relay 32 through to bit 0 of byte 5 which is relay 1.

| Byte 2 | | | | | | | | Byte 3 | | | | | | | | Byte 4 | | | | | | | | Byte 5 | | | | | | | |
|--------|----|----|----|----|----|----|----|--------|----|----|----|----|----|----|----|--------|----|----|----|----|----|----|---|--------|---|---|---|---|---|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |

If the bit is set the relay is on, off otherwise.

0x34 0x01 Get Input (2 byte command – returning 2 bytes)

This command is used to get the states of the inputs. The second byte is the input number, input 1 in this case.

The first returned byte is the state of the requested input, 0x00 (inactive) or 0x01 (active) the second byte packs the states of all 8 inputs. Bit 7 is input 8 through to bit 0 which is input 1. If the bit is high the input is active.

| | Byte 2 | | | | | | | |
|---------|--------|---|---|---|---|---|---|---|
| Bit No. | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Input | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |

packet. For example when you send a Get Status command (0x30) you will get a 16 byte block returned. The first 8 bytes (0-7) will be as defined for the binary commands. Bytes 8-11 are unused. Bytes 12-15 contain the Nounce.

Commands which generate and send you a Nounce are:

0x30 – Get Status
0x31 – Set Relay
0x32 – Set Output

Commands which require a Nounce to be sent by you are:

0x31 – Set Relay
0x32 – Set Output

A Nounce is only ever used once, you must always use the most recently issued Nounce.

The following example shows how the Nounce provided by the module is used in the next Set Relay or Set Output command.

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
|------------|------|------|------|------|------|------|------|------|----|----|----|----|------|------|------|------|
| Get Status | 0x30 | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx |
| Response | 0x1E | 0x02 | 0x12 | 0x01 | 0x02 | 0x7D | 0x01 | 0x0B | xx | xx | xx | xx | 0x89 | 0xAB | 0xCD | 0xEF |
| Set Relay | 0x31 | 0x02 | 0x01 | 0x00 | 0x00 | 0x00 | 0x00 | xx | xx | xx | xx | xx | 0x89 | 0xAB | 0xCD | 0xEF |
| Response | 0x00 | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx | 0x1A | 0x2B | 0x3C | 0x4D |
| Set Relay | 0x31 | 0x03 | 0x01 | 0x00 | 0x00 | 0x00 | 0x00 | xx | xx | xx | xx | xx | 0x1A | 0x2B | 0x3C | 0x4D |
| Response | 0x00 | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx | 0xF1 | 0xE2 | 0xD3 | 0xC4 |
| Set Output | 0x32 | 0x04 | 0x01 | xx | xx | xx | xx | xx | xx | xx | xx | xx | 0xF1 | 0xE2 | 0xD3 | 0xC4 |
| Response | 0x00 | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx | xx | 0x5C | 0x47 | 0x9B | 0xED |

If the Nounce you send with the command does not match the last one sent to you, then the Relay (or Output) will not be changed.

No other commands either require or provide a Nounce.

Modbus commands

The modbus command set accepts a subset of the standard Modbus-TCP frames as defined in [Modbus protocol Specification](#) and [MODBUS Messaging on TCP/IP Implementation Guide V1.0b](#)

Functions 1, 4, 5 & 15 are supported along with error codes 1, 2 & 3 should they occur.

Function 01 (0x01) Read Coils

This function reads back the 4 relays as coils 1-4, the virtual relays as coils 5-32 and the 8 I/O's as coils 41-48.

Function 04 (0x04) Read Input Registers

This function reads back the 4 analogue inputs as registers 1-4

Registers 5-8 are always zero

Registers 9-24 are 16 registers representing 8 counter values. As modbus registers are 16-bits wide and the counters are 32-bit, a counter is stored in 2 16-bit registers, high word first. In the same way, the 16 registers 25-40 hold the 8 capture values.

| | | | |
|-------------|--------------------|-------------|--------------------|
| Register 9 | Counter1 high word | Register 25 | Capture1 high word |
| Register 10 | Counter1 low word | Register 26 | Capture1 low word |
| Register 11 | Counter2 high word | Register 27 | Capture2 high word |
| Register 12 | Counter2 low word | Register 28 | Capture2 low word |
| Register 13 | Counter3 high word | Register 29 | Capture3 high word |
| Register 14 | Counter3 low word | Register 30 | Capture3 low word |
| Register 15 | Counter4 high word | Register 31 | Capture4 high word |
| Register 16 | Counter4 low word | Register 32 | Capture4 low word |
| Register 17 | Counter5 high word | Register 33 | Capture5 high word |
| Register 18 | Counter5 low word | Register 34 | Capture5 low word |
| Register 19 | Counter6 high word | Register 35 | Capture6 high word |
| Register 20 | Counter6 low word | Register 36 | Capture6 low word |
| Register 21 | Counter7 high word | Register 37 | Capture7 high word |
| Register 22 | Counter7 low word | Register 38 | Capture7 low word |
| Register 23 | Counter8 high word | Register 38 | Capture8 high word |
| Register 24 | Counter8 low word | Register 40 | Capture8 low word |

Function 05 (0x05) Write Single Coil

This function is used to write to a single coil (relay or I/O). Coils 1-4 are the relays 1-4. Virtual relays 5-32 are coils 5-32. Coils 41-48 are the I/O's 1-8 remapped to 41-48.

Function 15 (0x0F) Write Multiple Coils

Use this function when you need to write to multiple relays and I/O's at the same time. Coils 1-4 are the relays 1-4. Virtual relays 5-32 are coils 5-32. Coils 41-48 are the I/O's 1-8 remapped to 41-48.

Error code 1

This error is returned if an unknown or unimplemented function is received. Only functions 1, 4 & 5 are implemented.

Error code 2

This error is returned if an illegal address is requested. Addresses greater than 15 for functions 1 & 5 or greater than 7 for function 4 will generate this error.

Error code 3

This error is returned if an illegal data value is received. Number of points = zero will generate this as will an illegal data value for function 5.

Modbus Gateway

If the Modbus/TCP/IP frame has a UID that does not match the one you set in the TCP/IP config screen, the module will assume this is for another Modbus module connected to the RS485 port. It will use the UID as the Module address, convert the request to RTU format and send it to the downstream module. This could be an MBH88 for example. The return frame is then converted back to Modbus/TCP/IP format and returned to you.

Make sure you set the Parity and Baud Rate in the TCP/IP config screen to match your Modbus RTU modules.

Loading the application firmware

If your module does not flash the blue LED three times on power-up, you will need to update the system firmware and load the application program. These instructions should also be followed if you want to update your firmware to the latest version or even revert to an earlier version.

You need to download the dScript programming environment from here:

<http://www.robot-electronics.co.uk/dscript.html>

Select the Windows, Linux or MAC OSX version as required.

PC requirements

Windows 7 or later, Linux or MAC OSX operating system.

USB port to program the module.

The dScript IDE is supplied as a zip file that can be download and unzipped into a temporary folder, inside the temporary folder will be five folders:

Installation

USBdriver

Examples

Documentation

Utilities

Go to the Installation directory and click "setup" to install the dScript IDE, if you have already installed a previous version you will need to uninstall it before installing the new one.

The USBdriver folder contains the USB com port driver for the modules.


Copy the Examples directory to a convenient location on your computer, it contains both dScript source code examples and associated web pages, one of which is the application firmware you will need.

In this order:

1. Start from this position:
 - a. dScript Editor closed down.
 - b. dS3484 not connected or powered.
2. Power-up the dS3484.
3. Hold down the reset button for a couple of seconds until the red LED comes on. This indicates the module is in boot-loader mode.
4. Connect the USB lead to the PC. If windows wants a driver, point it to the USB driver


folder and install the driver from there.

5. Run the dScript editor. Look in Help→About and check you have the latest version of dScript.



6. If you have an earlier version you should uninstall it and install the new version from the installation folder, then start these instructions from the beginning. Older versions will not work with the new application.

7. Now look in the Module panel, you should see:



v1.1 indicates it's the boot-loader that is running.

8. Load the project: File→Open project
\\dScriptPublish-4-03\Examples\app-dS3484-v4-03\app-dS3484-v4-03.dsj

9. Click the build button (white triangle on green button). This will update the system firmware and load the application.



10. When done, the new version will be displayed:

Erasing old configuration settings

Uploading the firmware, as described in the previous section, will not erase all the configuration values. If you need to clear these, do the following:

Load up the app-dS3484-v4-03 application in the editor, but before you upload it to the dS3484 you need to make a small change. Locate the thread "main" (click the word in the right panel is quickest). Just below this is a commented out line "init()".

```
2799      threadsleep 10
2800      loop
2801  endwhile
2802
2803  thread main(const)
2804      if initControl != AppVersion Init()          ; init module if different from app version
2805      / Init()                                     ; uncomment this line to force init
2806
2807      if System_RLY_PUR&0x00000001 Rly1 = RelayStore[0]      ; restore relay states on power u
2808      if System_RLY_PUR&0x00000002 Rly2 = RelayStore[1]
2809      if System_RLY_PUR&0x00000004 Rly3 = RelayStore[2]
2810      if System_RLY_PUR&0x00000008 Rly4 = RelayStore[3]
2811      if Svstem RLY_PUR&0x00000010 Rlv5 = RelavStoref41
```

```
Binary()
CalcVoltsTemp(1000)
DoBinary()
DST(UseDST)
generateEmailMsg()
GetAttachedRly()
GetNonce()
Init()
main(const)
ModBus()
ModBus_ReadCoils()
```

Uncomment this by removing the semicolon.


```
2799      threadsleep 10
2800      loop
2801  endwhile
2802
2803  thread main(const)
2804      if initControl != AppVersion Init()          ; init module if different from app version
2805      Init()                                     ; uncomment this line to force init
2806
2807      if System_RLY_PUR&0x00000001 Rly1 = RelayStore[0]      ; restore relay states on power u
2808      if System_RLY_PUR&0x00000002 Rly2 = RelayStore[1]
2809      if System_RLY_PUR&0x00000004 Rly3 = RelayStore[2]
2810      if System_RLY_PUR&0x00000008 Rly4 = RelayStore[3]
2811      if Svstem RLY_PUR&0x00000010 Rlv5 = RelavStoref41
```

```
Binary()
CalcVoltsTemp(1000)
DoBinary()
DST(UseDST)
generateEmailMsg()
GetAttachedRly()
GetNonce()
Init()
main(const)
ModBus()
ModBus_ReadCoils()
```

Now upload the application and it will reset the IP address along with all other variables. Confirm the board is operating, but don't change anything yet.

You need to replace the semicolon and upload the application again, otherwise it will continue to reset everything each time you power-up.

dS3484 hardware



The dS3484 provides four (4) volt free contact relay outputs with a current rating of up to 16Amp each, 8 digital I/O's which can be an NPN transistor output or accept a volt free input (from relay or switch contacts, etc). 4 analogue inputs (0-3.3v level), 2 serial ports (3.3v level) and an RS485 serial port. The module is powered from a 12vdc supply which can be regulated or unregulated. The relays are SPCO (Single Pole Change Over) types. The normally open, normally closed and common pins are all available on the screw terminals.

LED indication

The dS3484 provides a red LED mounted immediately next to each relay to indicate whether it is in a powered state (LED on), there are also two LED's mounted in the Ethernet connector which will flash with Ethernet traffic. A row of three LEDs, Blue, Green and Red, are available to the user for status indication. There are also 2 LED's for module status, the Red LED lights when the module is in bootloader mode – this is when the IDE is uploading system firmware to the module. The Green LED lights the board begins running user programs. The three user LEDs are available and can be controlled as digitalports 33-35.

| | | |
|--------------------------|----------|----|
| <code>digitalport</code> | LedBlue | 33 |
| <code>digitalport</code> | LedGreen | 34 |
| <code>digitalport</code> | LedRed | 35 |

The "FlashingLeds" example provides a colourful display showing how to use them.

Power supply

The dS3484 requires a 12v DC supply capable of supplying a minimum of 1A. This is most easily provided by a low cost mains adapter. A suitable universal adapter is available on our website and may be ordered along with the modules. Connection is via the 2.1mm DC jack socket. Positive on the center pin.


Operating temperature

-40C to +70C


Power relays

Four 16A volt free contact relays are provided for switching a common input between a normally closed output and a normally open output. The relay coil is powered by the 12vdc incoming supply on user command.

Relay in passive state



Relay in powered state



A full datasheet for the relays used on the dS3484 is here: [HF115FD datasheet](#)

Digital IO

Our Ethernet modules could potentially have many types of outputs. For example the ETH008 only has one type - Relays. The dS3484 has both Relay outputs and NPN Open Collector Transistor outputs. Activating a relay means turning the relay on. Likewise activating an output means turning the transistor on. This will cause it to sink current to 0v ground. If you had an LED connected from the output to 12v (via a resistor of course) it would light up. Other modules (not this one) could have PNP Open Collector Transistor outputs. These types will source current from the supply when active.


So here's the point: Active does not mean a high voltage comes out. It means that the output has been activated. That could result in the output sinking or sourcing current, depending on its type. The outputs will sink current (up to 100mA max.) when active.

The same principle applies to the inputs, these are designed to allow you to directly connect a VFC (Volt Free Contact). This could be from other relay contacts, thermostat contacts, alarm contacts etc. When the contacts are closed the input will read as active. In fact anything that pulls the input pin down to 0v will read as active. Do not think of the I/O in terms of a high or low voltage output. Think of it in terms of Active (or on, something is actively driving the I/O), or inactive (or off, nothing is driving the I/O). It's a subtle point but one you need to be clear on.

Connection Examples


Example input - connecting a switch

Connecting a simple switch could not be easier, just wire the switch between a pin (P) and ground (G). When the switch closes the input will become active.




Example output - connect a relay

You can connect your own 12V relays, the first coil pin of the relay is wired to the 12V supply terminals on the board, the other is wired to the output pin (P). When the output pin becomes active it is driven down to 0V ground, the relay will have 12V across the terminals and switch so COM is connected to NO.



Representative Digital I/O Schematic




Analogue inputs

Four independent analogue input channels are provided for sampling voltages up to 3.3V. Each channel is also filtered with a 10k resistor and a 100n capacitor to stabilise high frequency jitter, there is also a pull down resistor so the port will read around 0 when nothing is connected. 5V inputs can be used, although the 3.3V to 5V region will merely read full scale.


Examples

Example input - connecting a potentiometer

Connecting a potentiometer should be the simplest of tasks, either end of the pot should be wired to the 5v and 0v respectively, the output pin of the pot is then wired into the analogue (A) pin. Please note the reading from the conversion will reach maximum at 3.3V.



Representative Analogue Schematic




Serial Port Connections

TTL serial ports.

The dS3484 has two serial port headers. Pin 1 is marked on the PCB.

Tx and Rx operates at 3.3v levels, however the Rx input is 5v tolerant. Most 5v TTL level serial ports will accept a full 3.3v input ensuring the port is compatible with most 5v devices such as the LCD05 display modules. That is the reason 5v (rather than 3.3v) is available on pin1 to power external modules.




RS485 serial port.


The 12v power is not part of the RS485 specification, it is there to provide convenient power for any 12v sensors you may wish to connect such as our SRF485 ultrasonic rangers.

Connections for the RS485 port are also clearly labelled on the PCB.

The two pin link near to the RS485 terminal block should be shorted to use the on-board 120 ohm terminating resistor.



dS3484 dimensions



Notes