Home (https://bluerobotics.com) / Guide (https://bluerobotics.com/learn/) / BlueROV2 Software Setup

BlueROV2 Software Setup

Guides in this Series א



BlueROV2 Assembly

(https://bluerobotics.com/learn/bluerov2-assembly/) Get your BlueROV2 built quickly with this assembly guide!



BlueROV2 Software Setup

(https://bluerobotics.com/learn/bluerov2-software-setup/)

Get your BlueROV2 connected to a topside computer, the vehicle updated, and joystick properly calibrated!



BlueROV2 Operation

(https://bluerobotics.com/learn/bluerov2-operation/) Learn how to operate your newly built BlueROV2!

Software Introduction %

These are instructions for the first time that you set up your computer to work with the BlueROV2. If you have not assembled your BlueROV2, please see our Assembly Guide (/learn/bluerov2-assembly/) and assemble your BlueROV2 prior to setting up the software.

Select your operating system below to begin the installation and network configuration:



QGroundControl Installation, Network Setup and Joystick Setup %

Install QGroundControl for Windows %

To connect your computer to the BlueROV2, you need to download and install QGroundControl:

This is the current software version (updated 28 April 2019):

- QGroundControl: v3.5.2 (release notes (https://docs.qgroundcontrol.com/en/releases/release_notes.html))
 - Windows (https://s3.amazonaws.com/downloads.bluerobotics.com/QGC/latest/QGroundControlinstaller.exe)

Windows Network Setup %

Network Settings %

1. Go to Control Panel > Network and Sharing Center and then choose "Change adapter settings".

and the stating center	Danal - All Canteri Danal Itana - Naturalia	d Sharing Castra		C	
ontrol Panel Home	View your active networks	nation and set up connections	~ 0	Search Control Panel	
hange advanced sharing ettings	BlueRobotics Public network	Access type: Internet Connections: M Wi-Fi (BlueRobotics)			
	Unidentified network Public network	Access type: No network access Connections: Q Ethernet 2			
	Change your networking settings				
	Set up a new connection or net Set up a broadband, dial-up, or	work VPN connection; or set up a router or access point.			
	Troubleshoot problems Diagnose and repair network pr	roblems, or get troubleshooting information.			
ee also					
omeGroup					
frared					
term of Castin and					

(https://bluerobotics.com/wp-content/uploads/2019/03/network-and-sharing-center-annotated.png?x62571)

2. Right click on the Ethernet adapter, then choose *Properties*.

		· • • • • • • • • • • •
Organize Disable this network device	Diagnose this connection Rename this connection View sta	tus of this connection Change settings of this connection 🐩 👻
Ethernet Network cable unplugged Intel(R) Ethernet Connection (2) I	Wi-Fi BlueRobotics Qualcomm Atheros AR9287 Wirel	network 9 USB 3.0 to Gigabit E

3. In the properties dialog, choose Internet Protocol Version 4 (TCP/IPv4), then click Properties.

Ethernet 2 Properties	\times
Networking Sharing	
Connect using:	
🚅 Realtek USB FE Family Controller	
Configure	
This connection uses the following items:	
Client for Microsoft Networks	
File and Printer Sharing for Microsoft Networks	
🗹 🐙 QoS Packet Scheduler	
Internet Protocol Version 4 (TCP/IPv4)	
L Microsoft Network Adapter Multiplexor Protocol	
Microsoft LLDP Protocol Driver	
Internet Protocol Version 6 (TCP/IPv6)	'
< >	
Install Uninstall Properties	
Description	
Transmission Control Protocol/Internet Protocol. The default	
wide area network protocol that provides communication	
across diverse interconnected hetworks.	
UK Cancel	

(https://bluerobotics.com/wp-content/uploads/2019/03/internet-protocol-version-4-annotated.png?x62571)

4. Select "Use the following IP address" And enter 192.168.2.1 for the IP address and 255.255.255.0 for the Subnet mask. Then select OK.

nternet Protocol version 4 (TCP/IPv4) Proper
--

 \times

General	
You can get IP settings assigned autor this capability. Otherwise, you need to for the appropriate IP settings.	natically if your network supports ask your network administrator
Obtain an IP address automatical	ly
• Use the following IP address:	
IP address:	192.168.2.1
Subnet mask:	255 . 255 . 255 . 0
Default gateway:	
Obtain DNS server address auton	natically
• Use the following DNS server add	resses:
Preferred DNS server:	
Alternate DNS server:	
Validate settings upon exit	Advanced
	OK Cancel

(https://bluerobotics.com/wp-content/uploads/2019/03/static-ip-annotated.png?x62571)

Firewall %

1. Go to *Control Panel > Windows Firewall* and then select "Allow an app or feature through Windows Firewall".

2. Select "Change Settings" and then select "Open source ground control app provided by QGroundControl dev team" or "QGroundControl".

Allowed apps							×
← → ~ ↑ 🔗 > Control Panel > All Co	ntrol Panel Items > Windows Firewall > Allowed apps			,	v ₽	Search Control Panel	,P
	Allow apps to communicate through Windows Firewall						
1	To add, change, or remove allowed apps and ports, click Change settings.						
	What are the risks of allowing an app to communicate?	🛛 🌍 Ch	ange setti	ngs			
	Allowed apps and features:						
	Name	Private	Public	^			
	Microsoft Sticky Notes	V					
	Movies & TV	Y					
	MSN Weather	V	\checkmark				
	Netlogon Service						
	Network Discovery	V					
	☑ OneNote	V	Y				
	Open source ground control app provided by QGroundControl dev team) 🗹					
	Performance Logs and Alerts			1			
	Proximity Sharing	V	\checkmark				
	Raptr Desktop App		V				
	Raptr IM		Y				
	Remote Assistance	V		~			
		Details	Remove	1			
		Allow ar	other ann				
		741011 01	iourici opp				
		OK	Canc	el			

(https://bluerobotics.com/wp-content/uploads/2019/03/windows-firewall-annotated.png?x62571)

Joystick Setup %

Initial Setup for XBox Controllers on Windows %

For using the shift button functionality of XBox Controllers on Windows:

- 1. Go to Start -> Settings
- 2. Open the Gaming settings



(https://bluerobotics.com/wp-content/uploads/2019/03/settings.png?x62571)

- 3. Go to Game Bar tab from the left navigation panel
- 4. Uncheck the 'Open Game bar using this button on a controller' option

← Settings		- • ×
Home	Game bar	
Find a setting	Control how Game bar opens and recognizes your game	Record game clips
Gaming	Record game clips, screenshots, and broadcast using Game bar	Press the Windows logo key and the G key to start taking screenshots and recording game clips when playing a game.
📼 Game bar	Open Game bar using this button on a controller: 🏼 🏵	Get more info about Game bar
더 Game DVR 양 Broadcasting	Show Game bar when I play full screen games Microsoft has verified	Have a question? Get help
Game Mode Game Mod	Keyboard shortcuts	
S TruePlay	Open Game bar Windows shortcut Win+G	Make Windows better Give us feedback
⊗ Xbox Networking	Your shortcut	
	Take screenshot Windows shortcut Win+Alt+PrtScrn Your shortcut	
	Windows shortcut Win+Alt+G Your shortcut	
	Start/stop recording Windows shortcut Win+Alt+R	
	Your shortcut	
	Show recording timer Windows shortcut Win+Alt+T	
	Your shortcut	
	Microphone on/off Windows shortcut Win+Alt+M	

(https://bluerobotics.com/wp-content/uploads/2019/03/gamebar.png?x62571)

This will enable the XBox home button on the controller to be used as the Shift button for ROV controls.

XBox 360 Controller 🗞

• Plug and Play

XBox One Controller 🗞

- Wired: Plug and Play
- Wireless:
 - 1. Plug in Microsoft XBox Wireless Adapter for Windows (https://www.microsoft.com/en-us/p/xboxwireless-adapter-for-windows-10/91dqrb97l130/jq56? cid=msft_web_collection&activetab=pivot%3aoverviewtab).
 - 2. Turn on the controller, then press the Wireless Enrollment button on the top of the controller and on the wireless adapter.

Logitech GamePad (F710 and F310) %

• Logitech controllers should have the switch on the back set to "X".

Testing the Connection to the BlueROV2 %

1. With the BlueROV2 still connected and powered on, start the QGroundControl application.

2. Wait a few seconds for the ROV to auto-connect and the green parameters bar to finish loading from left to right.

3. The video stream and telemetry information should now be shown in the QGroundControl application.



If the video stream is not shown or the vehicle does not connect, please follow the ArduSub Troubleshooting Guide (https://www.ardusub.com/troubleshooting/troubleshooting.html) before contacting Blue Robotics Support.

Update Software %

There are two computers installed on the BlueROV2: a Pixhawk autopilot, and a Raspberry Pi 'companion' computer. Before proceeding, we will check that the software on both computers is up to date, and update the software if necessary.

These are the current software versions (updated 15 April 2019):

- Companion: v0.0.17 (release notes (https://github.com/bluerobotics/companion/blob/master/release-notes.txt))
- ArduSub: v3.5.4 (release notes (https://github.com/ArduPilot/ardupilot/blob/master/ArduSub/ReleaseNotes.txt))

Companion %

Companion is the software that runs on the Raspberry Pi. To perform a companion software update:

1. Plug a _fully charged_ battery into the ROV and connect the tether to your computer.

2. Navigate to 192.168.2.2:2770/network (http://192.168.2.2:2770/network) in your browser and ensure that the ROV has access to a WiFi network. If you do not see a webpage at this address, you need to perform the update according to the instructions here (http://discuss.bluerobotics.com/t/software-updates/1128).

3. Navigate to 192.168.2.2:2770/system (http://192.168.2.2:2770/system). Click the button that says 'Update companion'. If you do not see this button, then the companion software is up to date.

4. The update process will take between 5 and 20 minutes depending on the Internet connection speed. Wait for the update process to complete.

5. When it completes, refresh your browser. The companion version should be updated, and the update available message should no longer appear.

6. If the update fails (usually due to a loss of internet connectivity), you will be warned that the ROV will reboot and to leave the battery plugged in. At this point, once you are able to refresh the webpage, it is safe to either power down the ROV or attempt the update again.

ArduSub 🗞

ArduSub is the software that runs on the Pixhawk autopilot. To perform an ArduSub software update:

1. Navigate to 192.168.2.2:2770/network (http://192.168.2.2:2770/network) and ensure that the RC' ' has an internet connection.

2. Navigate to 192.168.2.2:2770/system (http://192.168.2.2:2770/system). Click the button under the 'Pixhawk Firmware Update' section that says 'Stable'.

3. Wait for the update process to complete, and you are finished!

Joystick/Gamepad Calibration %

Some joysticks require calibration before you can enable them for use with QGroundControl. If your joystick requires calibration, the **Joystick** tab on the **Vehicle Settings** page will be red, and you should follow these steps to calibrate your joystick. If your joystick does not require calibration, the **Joystick** tab will not be red, and you can skip this step!

1. Go to the **Vehicle Settings** page in QGroundControl, then click on the red **Joystick** tab in the sidebar on the left.

2. Ensure the 'TX Mode' selection is set to 3.

3. Click "Calibrate", then click "Next".

4. Follow the step-by-step instructions, move the sticks as indicated in the diagram in QGroundControl.

When completed, the **Joystick** tab will no longer be red, and the **Enabled** checkbox on the Joystick page should be checked.

Button Setup %

The default button setup for the BlueROV2 is as shown in the image below:



(https://bluerobotics.com/wp-content/uploads/2019/03/joystick-defaults.png?x62571)

The button functions may be reconfigured in the **Joystick** tab on the **Vehicle Settings** page.

Sensor Calibration %

1. Go to the **Vehicle Settings** page in QGroundControl and select the red *Sensors* tab in the sidebar on the left.

2. Choose `Roll90` for the **Autopilot Orientation** selection.

- 3. Click on the Accelerometers and follow the instructions.
- 4. Click on *Compass* and follow the instructions.

When completed, the Sensors tab will no longer be red.

Configure Motor Directions %

The motor directions for the BlueROV2 must be configured prior to operation.



Be sure to keep all body parts and clothing clear of thrusters while the BlueROV2 is armed.



DO NOT run thrusters for longer than 30 seconds in air or you will wear out the plastic bearings.

- 1. Go to the Vehicle Settings page in QGroundControl and select the *Motors* tab in the sidebar on the left.
- 2. Read and understand the instructions on the setup page.
- 3. Arm the BlueROV2 by clicking the switch on the page.

4. One at a time, move each slider, and make sure that the motor that spins is pushing air in the correct direction. If a motor is spinning in the wrong direction, click the corresponding checkbox under the 'Reverse Motor Direction' section to correct the motor rotation.

5. When you are finished with the setup, disarm the ROV by clicking the switch.



(https://bluerobotics.com/wp-content/uploads/2019/03/brov2-standard-motor-directions.png?x62571)

Voltage and Current Measurement Setup %

Follow the respective guide for your Power Module (depreciated) or Power Sense Module (current).



Power Sense Module (PSM) Installation

(https://bluerobotics.com/learn/power-sense-module-psm-installation/)

Learn how to install and setup a Power Sense Module on your BlueROV2 or other underwater project! **SOS Leak Sensor Setup** %

In the Safety tab, select "Pixhawk Aux6" as the leak detector pin, and set the Logic when dry to "Low."



(https://bluerobotics.com/wp-content/uploads/2019/01/sos-software.png?x62571)

To The First Dive! %

Your computer setup is now complete! Please see our Operation Manual to finish getting ready for your fi Privacy-Terms



BlueROV2 Operation

(https://bluerobotics.com/learn/bluerov2-operation/) Learn how to operate your newly built BlueROV2!

Issue Reporting %

We're always trying to make our documentation, instructions, software, and user experience better. If you're having an issue with anything, please report it so that we can address it as soon as possible! Here's where to do that depending on what's wrong:

- **ArduSub Issues:** For anything related to the ArduSub software that runs on the Pixhawk and controls the ROV, reports issues on the ArduSub Github Issues Page (https://github.com/bluerobotics/ardusub/issues). If you're unsure where your issue should be posted, you can report it here.
- **QGroundControl Issues:** For anything related to the QGroundControl software, joystick setup, video streaming, etc., please report an issue on the QGroundControl Github Issues Page (https://github.com/mavlink/qgroundcontrol/issues).
- **Documentation:** For anything related to the documentation and instructions here, please report an issue by submitting an e-mail to support@bluerobotics.com (mailto:support@bluerobotics.com).

Navigation
Guides in this Series
Software Introduction
QGroundControl Installation, Network Setup and Joystick Setup
Testing the Connection to the BlueROV2

Update Software
Joystick/Gamepad Calibration
Button Setup
Sensor Calibration
Configure Motor Directions
Voltage and Current Measurement Setup
SOS Leak Sensor Setup

To The First Dive!

Issue Reporting

🔒 Print

Tags

BlueROV2 (https://bluerobotics.com/guide-tag/bluerov2/)

Posted 21 Jun 2016 Last updated on 14 May 2019



BlueRobotics

Blue Robotics provides high-quality, low-cost components, parts, and supplies for marine robotics.

Blue Robotics Home (/) About Us (/about/) Blog (/blog/) Gallery (/gallery/) Technology (/technology/) Software and Hardware (/software-and-hardware/) Store Visit the Store (/store) Distributors (/distributors) Ordering & Shipping Info (/order-shipping-info/) Return Policy (/terms/#returns) **Support & Community** Documentation (//docs.bluerobotics.com) Forums (http://discuss.bluerobotics.com) Video Tutorials (//docs.bluerobotics.com/videos/) Contact Contact Us (/contact/)

Copyright © 2019 - Blue Robotics Inc. | Contact Us (/contact/) | Terms and Conditions (/terms/#terms) | Privacy Policy (/terms/#privacy)

(mailto:info@bluerobotics.com)