

## Instructions Before Use


1) Bus Servo Control.exe is PC software of Bus servo controller.



2) Bus Servo Terminal is the parameter setting software of LX-224HV servo.



3) Before using the servo controller, please set the parameters and ID of the servo with the servo debug board (BusLinker). In general, you only need to set the ID.



4) The servo servo controller can be used to control the servos after the servo ID number being set.